

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105
 North Las Vegas, NV 89031
 TEL: 702-399-1423
 FAX: 702-399-1431
 8am-5pm Pacific Time
 Monday through Friday

Website Address
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.



E3153.003

European Models Only

1996-2000 Suzuki GSF1200 Bandit

Stage 1&3


STAGE 1

For mildly tuned machines using the stock airbox, with stock or K&N filter #SU-7593

STAGE 3

For mildly tuned machines using individual filters or velocity stacks. K&N filters #RU-2922

Both stages may be used with a good aftermarket exhaust



This graph shows a typical gain with a Dynojet jet kit.

WARNING


**NO SMOKING!
 NO OPEN FLAME!
 WHILE INSTALLING
 YOUR DYNOJET KIT**

Parts List

4	Main Jet	DJ100
4	Main Jet	DJ104
4	Main Jet	DJ150
4	Main Jet	DJ155
4	Fuel Needles	DNO400
4	E-Clips	DE0001
4	Adjusting Washers	DW0001
4	Slide Spring	DSP008

STAGE ONE INSTRUCTIONS

1. Remove vacuum slides from carbs. Remove stock needles and spacers, noting order of assembly (Fig.A).
2. Install the Dynojet needles on groove #2 from the top. Use all stock spacers (Fig. A). Install the small Dynojet washers above the e-clip. Install the Dynojet slide springs (DSP008) in place of the stock slide springs. After installing the slides in the carbs be sure to check slide movement manually.
3. Remove the stock main jets and replace with the Dynojet main jets provided. If you are running the stock exhaust install the DJ100 main jets. If you are running an aftermarket exhaust or slip-ons with a high flowing baffle use the DJ104 main jets. Be sure that the jet you are changing is the main jet.
4. Locate the fuel mixture plug (Fig. B). Carefully turn the mixture screw clockwise until lightly seated, then back out 1-3/4 turns or until the best idle is achieved.



STAGE THREE INSTRUCTIONS

DYNOJET

E3153.003

1. Remove vacuum slides from carbs. Remove stock needle and spacers, noting order of assembly (Fig.A).
2. Install the Dynojet needles on groove #2 from the top. Use all stock spacers (Fig. A). Install the small Dynojet washers above the e-clip. Install Dynojet slide springs (DSP008) in place of the stock slide springs. After installing the slides in the carbs be sure to check slide movement manually.
3. Remove the stock main jets and replace with the Dynojet main jets provided. If you are running the stock exhaust install the DJ150 main jets. If you are running an aftermarket exhaust or slip-on with high flowing baffle use the DJ155 main jets. Be sure that the jet you are changing is the main jet.
4. Locate the fuel mixture plug (Fig. B). Carefully turn the mixture screw clockwise until lightly seated, then back out 1-3/4 turns or until the best idle is achieved.

