

Thank you for purchasing this Dynojet kit. This kit has been developed for a motorcycle which is set to the parameters listed at the right in the "Stage" description. If your motorcycle does not meet any of these parameters please check with Dynojet before installation. For technical assistance contact your Dynojet distributor or call Dynojet U.S.A. (800)-992-4993

2191 Mendenhall Dr. Suite 105  
 North Las Vegas, NV 89031  
 TEL: 702-399-1423  
 FAX: 702-399-1431  
 8am-5pm Pacific Time  
 Monday through Friday

Website Address  
<http://www.dynojet.com>

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.



**E4181.001**


European Models Only

*1997-02 Yamaha Fazer 600*

**Stage 1**

For mildly tuned machines using the stock airbox, with stock or K&N filter. May also be used with a good aftermarket exhaust system.

K&N filter # N/A



*This graph shows a typical gain with a Dynojet jet kit.*

# WARNING

**NO SMOKING!  
 NO OPEN FLAME!  
 WHILE INSTALLING  
 YOUR DYNOJET KIT**

Parts List		
4	Main Jets	DJ106
4	Main Jets	DJ108
4	Main Jets	DJ110
4	Main Jets	DJ112
4	Fuel Needles	DNO712A
4	E-Clips	DE0001
4	Adjusting Washers	DW0001
4	Needle Springs	DSP77

## STAGE ONE INSTRUCTIONS

1. Remove the vacuum slides from the carbs. Remove the stock needles and spacers, noting the order of assembly (Fig. A).
2. Install the Dynojet needles on groove # 1 from the top. Use all stock spacers (Fig. A). The small Dynojet washers are for half step increments and do not have to be installed at this time. **NOTE:** The DSP77 springs do not have to be used, they are supplied in case the stock springs are misplaced. After installing the slides in the carbs be sure to check slide movement manually.
3. Remove the stock main jets and install the Dynojet main jets provided. If you are running the stock exhaust install the DJ108 main jets. If you are running an aftermarket exhaust or slip-on with a high flowing baffle, use the DJ110 main jets. The extra main jets are for high altitude applications. Be sure that the jet you are changing is the main jet.
4. Locate the fuel mixture plug (Fig. B). Carefully turn mixture screws clockwise until lightly seated, then back out 2.5 turns.

**DYNOJET**

**E4181.001**




Fig.A




Fig. B Mixture Screw Location

